



# Applicable brand and code list

Brand	Code	Brand	Code	Brand	Code	Brand	Code	Brand	Code	Brand	Code	Brand	Code
ACCOM	980	DAJINXING	329-330	HYUNDAI	780-789	PEREG	988	TADIAIR	901-508-908,532				
ADC	861	DAKE	861	INYCIN	475-483	PIKING/AMUR/40	280	TADRAN	501-508-509,532-530,968,978-979,991				
AIDELONG	293-295	DAOTIAN	821-824	JIANGNAN	359	PILOT	902						
AITE	296-299	DELONGHI	900	JIALE	358	PUYI	862						
AKIRA	796-797	DUNAN	336	JIMSTAR	360	QIXING	393	TAIYA	862				
AMCOR	501-508-509,532,973-979,979	DONGXIA	334-335	JINBEIJING	361-362	RAYBO	371-383	TCL	120-139				
AMICO	982	DONGXINBAO	260-268	JINDA	491-492	RHOSS	903	TEAC	850-859				
ALPIN	989-991,998	ELECO	982	JINSONG	363-365	RICAI	394	TECO	831-834				
AUCMA	210-229	ELECTER	981-986	JOHNSO	282	RIJIANG	395-397	TIANJONGTAO	424				
AUX	180-199	ELECTROLUX	471-474	KANGLI	368-370	ROWA	383-385	TIANYUAN	425-428				
AOKE	301-302	FEDDERS	878	KELONG	110-119	SACON	414	TOBO	250-269				
AOLLI	300	FEIEDRICH	879	KLIMATAIR	797-800	SAMSUNG	610-629	TONGLI	429-430				
APTON	862	FEIGE	829-830	KONKA	368-367	SANYONEC	500-559,860	TOYO	825-828				
BAIXUE	299	FEILU	240-249	KRIS	804-805	SANZUAN	190	TOSHIBA	630-639				
BEIJINGJINJIAN	304	FERROLI	901	KT02 D001	283	SAPORO	861	TRANE	812-816				
BIG-THUMB	331	FIRST	864	KT02 D002	284	SAST	450-452	UNI-AIR	388-369				
BOERKA	630	FRESTECH	770-279	KTY001	285	SENSOR	860	UTILEDUCK	454-456				
BOERKA	305-306	FUJITSU	700-719	KTY002	286	SERENE	499	WANBAO	431-433				
BOSHI	310	GALANZ	140-149	KTY003	287	SHAMEI	400	WANGZI	861				
BOSHIGAO	308-309	GEER	342-343	KTY004	288	SHANGHONG	403-409						
BORLER	307	GLEE	280	KTY005	289	SHANYE	862	WEILI	434-443,553-576				
CAIXING	311	GOLDSTAR	303	LG	600-609	SHANXING	401-402	WEIHEIJI	444				
CARRIER	690-699,890-899	GREE	608-620-639	LIANGYU	780	SHARP	720-739	WHIRLPOOL	770-774				
CHANGFENG	190	GUANGDA	345-346	LIKEAIR	368-387	SHENBAO	410-411	WUFENG	445-446				
CHANGFU	835-838	GUJIAO	344	LITLESWAN	453	SHENGFENG	412	XINGHE	462-463				
CHANGLING	312-323	HAIER	001-019	LONGHE	861	SHENGKANG-FIELD	413	XINLE	457-460				
CHANGSHONG	960-079	HEILTON	863	LOREN-SEBO	801-803	SHINCO	200-209	XILENG	448-449				
CHENGYUAN	324	HEMILTON	095	MCQUAY	780-795	SHINING	415	XIONGDI	862				
CHIGO	980-099	HICON	391-392	MD	040-059	SHUANGLU	416-418	YAIR	467-471,044				
CHUANGHUA	325-328	HISENSE	230-239	MEILING	388-391	SIGMA	447	YAOMA	470				
CHUANYAN	861	HITACHI	640-659	MINGMINGBOYIN	290	SOGO	291	YIDONG	499				
COLROLLA	861	HONGYI	347	MTSUBISHI	551-599	SONGLINXIA	862	YORK	775-779				
CHUNLAN	170-179	HUABAO	100-109	MTSUKA	904	SONGXING	419	YUTU	484-490				
CONSUL	993	HUAGAO	348	NATIONAL Panasonic	660-689	SOVA	292	ZHONGYI	493-494				
CORONA	337-341	HUAKE	349-350	NIKKO	810-811	SOVA	420	ZHUODAN	495				
CORONA CROWN	861	HUAMEI	351-352	NISO	398-399	SOWA	862-863	DIY	044,090,092,095				
DAEWOO	332-333	HUANGHE	353	NORCA	497	SOYEA	421-422	OTHER	496,498,871-928,839-849,865-877,905,976,999				
DAIKIN	740-759	HUANGWEI	150-169	OLYMPUS	994	SRTC	987						
		HUIFENG	354-356	OPAL	997	STARHILL/ARCOM	880						
		HUIFENG	357,360	PANDA	464-466	SUNBURG	817-820						

3

Test whether the functions of remote control buttons (excluding Temperature and buttons, timed ON/OFF buttons, and SET button) are correct. If yes, the code is effectively set. If not, press SET button to continue onto the search.

## Set Time Function

Press CLOCK button (for three seconds) to enter the clock setting status, and the clock will flicker. Use the Temperature "▲" or "▼" buttons to adjust the current time, and press CLOCK button again to exit setting.



## Timing ON/OFF Function

To configure the timer function of the original remote control, press TIME ON or TIME OFF buttons, and the air conditioner timer lights will go on, indicating the air conditioner has entered the timed status.

The timed ON function of some of the air conditioner types is only valid only in the Power Off status.



- This remote control is effective if the air conditioner receiver works normally.
- If this remote control is intended to be not in use for a long time, please remove the batteries.
- If any possibly caused internal program disorder if this remote control is not operated correctly, in case of that, please to take out the battery, and install the batteries 35 minutes later, then the remote control may recover normal.